







IDIN Skill Builder: Charcoal Press Participant Guide




Mark the entire cut line to ensure a straight cut.



Use a thumb to stabilize the blade while initiating the cut.



Let the saw do the work.
More teeth for thinner material.






Cut at a 45 degree angle with force on the forward stroke only.




Use the whole blade. Line up the shoulder, arm and blade.





Mark where to cut.



Cut with the metal inserted as far as possible into the mouth



Cut at a 45 degree angle. Apply force in the direction of the cutting teeth




Use the whole blade. Line up the shoulder, arm and blade





Set up the work station by sketching on the wood and clamping the pieces down.



Define the edges.



When removing material, chisel toward the center, continuously alternating directions. Redefine the edges as needed.



Place the nail inset from the corner.



Hold hammer close to head for control; further down the handle for power.



Hold nail at angle, then rotate until perpendicular to the wood.

